





Find references



**ISO < 60**

**2-stage, conventional loading:** re-measure at follow-up > 2 months.

**Scientific references:** 1, 6.

Consider a conservative approach due to low implant stability (i.e., relatively high implant mobility).

Scientific references: 7, 8.

The above is a summary of scientific data and not an official recommendation by Osstell.

To monitor dental implant stability, measure at placement and prior to the final restoration.